


Inserted renewable date seal UYM.



UFM

1. From the subtype surface of mould, you can quickly replace the inserted parts without dismantling mould.
2. Ball Positioning;
3. The inserted parts can change its year, suitable for long-term production mould, so as to save cost of the mould.



UYM



UOM



UOY



UOD



UOR



UOS



UOB



UUM




UUY




UUD



UUR



UUS



UYB

Months+Year	Months	Year	Days (1-31)	1st digit	2nd digit	Blank	ϕD	L	ϕF
UYM_*_04	UOM0004	UOY_*_04	—	UOR0004	UOS0004	UOB0004	4	8	2.4
UYM_*_06	UOM0006	UOY_*_06	—	UOR0006	UOS0006	UOB0006	6	8	3.7
UYM_*_08	UOM0008	UOY_*_08	—	UOR0008	UOS0008	UOB0008	8	10	5.0
UYM_*_10	UOM0010	UOY_*_10	—	UOR0010	UOS0010	UOB0010	10	12	6.3
UYM_*_12	UOM0012	UOY_*_12	—	UOR0012	UOS0012	UOB0012	12	14	7.5
UYM_*_16	UOM0016	UOY_*_16	UOD0016	UOR0016	UOS0016	UOB0016	16	14	11.0
UYM_*_20	UOM0020	UOY_*_20	UOD0020	UOR0020	UOS0020	UOB0020	20	16	13.2

Please fill the beginning year on " * " when you make and order

Months	Year	Days (1-31)	1st digit	2nd digit	Blank	ϕD	L	ϕF
UUM0004	UUY_*_04	—	UUR0004	UUS0004	UUB0004	4	8	2.4
UUM0006	UUY_*_06	—	UUR0006	UUS0006	UUB0006	6	8	3.7
UUM0008	UUY_*_08	—	UUR0008	UUS0008	UUB0008	8	10	5.0
UUM0010	UUY_*_10	—	UUR0010	UUS0010	UUB0010	10	12	6.3
UUM0012	UUY_*_12	—	UUR0012	UUS0012	UUB0012	12	14	7.5
UUM0016	UUY_*_16	UUD0016	UUR0016	UUS0016	UUB0016	16	14	11.0
UUM0020	UUY_*_20	UUD0020	UUR0020	UUS0020	UUB0020	20	16	13.2

Please fill the beginning year on " * " when you make and order




Order:

Type No. x Pcs
UYM_*_04 x 10

Inner Pointer of Date Stamp YUU.

• Installation diagram



YUU



OUU

Year and Arrow	Arrow	L	ϕF
YUU_*_04	OUU0004	8	2.4
YUU_*_06	OUU0006	8	3.7
YUU_*_08	OUU0008	10	5.0
YUU_*_10	OUU0010	12	6.3
YUU_*_12	OUU0012	14	7.5
YUU_*_16	OUU0016	14	11.0
YUU_*_20	OUU0020	16	13.2


Fill in the start year after the model for order.

Date Stamp Series



Inserted renewable date seal
FYM.

American standard



FYM



FOM



FOY



FOD



FOR



FOS



FOB



OOM



OOY



OOD



OOR



OOS



OOB

Months+Year	Months	Year	Days (1-31)	1st digit	2nd digit	Blank	ϕD	L	ϕF
FYM*_04	FOM0004	FOY*_04	---		FOS0004	FOB0004	4	8	2.1
FYM*_06	FOM0006	FOY*_06	---	FOR0006	FOS0006	FOB0006	6	8	3.1
FYM*_08	FOM0008	FOY*_08	---	FOR0008	FOS0008	FOB0008	8	10	4.4
FYM*_10	FOM0010	FOY*_10	---	FOR0010	FOS0010	FOB0010	10	12	5.2
FYM*_12	FOM0012	FOY*_12	FOD0012	FOR0012	FOS0012	FOB0012	12	14	6.2
FYM*_16	FOM0016	FOY*_16	FOD0016	FOR0016	FOS0016	FOB0016	16	14	8.2
FYM*_20	FOM0020	FOY*_20	FOD0020	FOR0020	FOS0020	FOB0020	20	16	11

Please fill the beginning year on "*" when you make and order

Months	Year	Days (1-31)	1st digit	2nd digit	Blank	ϕD	L	ϕF
OOM0004	OOY*_04	---		OOS0004	OOB0004	4	8	2.1
OOM0006	OOY*_06	---	OOR0006	OOS0006	OOB0006	6	8	3.1
OOM0008	OOY*_08	---	OOR0008	OOS0008	OOB0008	8	10	4.4
OOM0010	OOY*_10	---	OOR0010	OOS0010	OOB0010	10	12	5.2
OOM0012	OOY*_12	OOD0012	OOR0012	OOS0012	OOB0012	12	14	6.2
OOM0016	OOY*_16	OOD0016	OOR0016	OOS0016	OOB0016	16	14	8.2
OOM0020	OOY*_20	OOD0020	OOR0020	OOS0020	OOB0020	20	16	11


Please fill the beginning year on "*" when you make and order



Order: Type No. x Pcs
FYM*_04 x 10

Inner Pointer of Date Stamp
YON.


• Installation diagram



YON



OON



Year and Arrow	Arrow	L	ϕF
YON*_04	OON0004	8	2.1
YON*_06	OON0006	8	3.1
YON*_08	OON0008	10	4.4
YON*_10	OON00010	12	5.2
YON*_12	OON00012	14	6.2
YON*_16	OON00016	14	8.2
YON*_20	OON00020	16	11

Order please * Please fill in first year

BRAHMADEVI ENGINEERING PRODUCTS

Regd. Office : 19, Martand Chowk, INDORE - 452 007 (M.P.) INDIA

Ph. : +91 - 731 - 2720243, Fax : +91 - 731 - 2721554

E-mail : ishan1809@yahoo.com, ruchir@dieaspares.com Website : www.dieaspares.com